

# LOADMASTER FT2-PV Installation Guide



---

## **GENERAL**

This scale system must be installed on a firm and level surface. Particular attention should be paid to the load bearing points at the end of each module. Note that if the area between the ends of the scale is too high it will cause weight errors by deflecting the sub-frame up into the bridge creating a bind. The same condition can be created if surface settling occurs, the center of the frame will not compress the surface at the same rate as the load bearing ends. This will create the same bind as the unlevel surface described above.

## **INSTALLATION STEPS**

1. Site preparation. You should have a firm and level surface area that is at least one (1) foot wider and five (5) feet longer than the overall dimensions of the scale. For a temporary installation compressed stone is adequate. For any installation over 6 months it is recommended that concrete footers be poured below frost level.

2. Determine where your indicator will be installed and arrange the scale so the J-Box is located on the same side. Note that the J-Box is located behind an access plate just to the left of the welded FT2 nameplate and serial tag.



3. Set the first module. It's important that you remove each access plate and hook your chains to the structural beams, DO NOT lift the scale by hooking on to the deck, side channel iron skirts, or smaller 3" I-beam stringers found under the manhole covers. Approx weight for the lift is as follows:
  - a. 10' (x10') module is 5,900 lb.
  - b. 15' module is 8,000 lb
  - c. 17'6" module is 9,100 lb
  - d. 20' module is 10,200 lb
  - e. 23'4" module is 11,600 lb
  - f. 25' module is 12,300 lb



4. Skip this step if this is NOT a three (3) bridge system with a center “dead” section.

Install module separators on to the end of the frame. By bolting with four  $\frac{3}{4}$ ” x  $2\frac{1}{4}$ ” bolts supplied. (Two each side)



5. Place end module in place and bolt to the either the separator channels (3 bridge system) or the other module (2 bridge system). Using four  $\frac{3}{4}$ ” x  $2\frac{1}{4}$ ” bolts supplied. (Two each side)

6. Skip this step if this is NOT a three (3) bridge system with a center “dead” section.  
Lower center bridge section between the two end scale sections.



7. Install splice bolts on all 4 corners of the center section. Using the 56  $\frac{3}{4}$ " x 2  $\frac{1}{4}$ " bolts supplied. (14 per corner)



8. Bolt the bulkheads to each end of the scale. Using four  $\frac{3}{4}$ " x 2- $\frac{1}{4}$ " bolts per end.



9. The optional steel ramps attach to the bulkheads, if you have ramps install them now. If you will be using a stone approach, build your approach now.

10. Remove the four shipping bolts. One located at each corner of the two end scale sections. It is suggested that you store them inside the scale so they are available when moving the scale.



11. Adjust the Bumper bolts to minimum of 1/8" and a maximum of 1/4" on all four corners of the scale sections. Total of eight bumpers per section.



12. All load cells should now be supporting some weight (check the tension on suspension links). If the installation surface is not perfectly level it may be necessary to do some shimming. Depending on the firmness of your installation surface it may be necessary to re-shim after some traffic has gone over the scale. To prevent overloading a corner (and for optimum accuracy), it's important that EACH load cell be supporting some weight without a load on the scale.
13. Each module is pre-wired internally to the junction box located under the center access plate found close to the center of the scale. Under that access plate you should also find the main cable coiled up for shipping. The main cable from one module is wired into the junction box of the next module and the main cable from that module is run to the digital indicator. Refer to drawing 241-1102-2 located at the end of this manual.
14. Your digital indicator (and printer if supplied) must be located inside a weather-proof building. This equipment is NOT weather-proof and must have a power source (110 VAC, portable generator or battery pack with inverter). Plug in your indicator and apply a concentrated weight to each load cell (human body is sufficient at this point). Each corner should read a weight within a graduation (20 lbs normally) of each other. If you see an error check your wiring – DO NOT ADJUST - look for broken wires or shorts caused by removing too much insulation at the terminal block. Once you have each corner weighing within a graduation THEN your scale is ready for calibration by a local scale servicing company.
15. Install deck cover plates AFTER simple corner check described above. Your scale is now ready for calibration with certified test weights.

## **CALIBRATION GUIDE**


1. Do NOT attempt to make any calibrations until all corners are weighing within a single graduation as described in the above section. Keep in mind that any adjustments should be minimal and doing it before the scale is properly setup will make things much more difficult.
2. Adjust sections. The goal is to apply a concentrated load over each section of the scale (or end of each module) and adjust them to indicate the same weight. The higher the weight the better. Once all the sections indicate the same weight then the overall calibration (see below) will be made to give you an accurate weight.
  - a. It's important to note that the load cells in each section are adjusted as a pair and that on a standard installation there is not an adjustment for individual load cells.
  - b. The section adjust pots are located in the summing box (by the indicator). Note that this is NOT the junction box found under the manhole in the scale.
  - c. If this is a "multi-module" installation it's important while adjusting sections to keep your concentrated load on a single module.
3. Overall calibration. Once all the sections have been adjusted and indicating within tolerance you will make an overall calibration in the digital indicator. This process varies greatly depending upon your make and model of indicator. If we supplied your indicator you should find an operators manual for that indicator included with this manual. Look up the section for calibration and follow those instructions.

# LOADMASTER FT2-PV Preparation for Transport

1. Remove all access covers, including the corners and the junction box cover.
2. **IMPORTANT** – disconnect the main cables, coil them up and store them **BEHIND** the junction box access plate. The access plate for the junction boxes can be put back in place now.
3. Adjust bumper bolts (see illustration provided in the installation section of this manual) back into shipping position to stop deck movement.
4. Install shipping bolts (see illustration provided in the installation section of this manual).
5. Remove splice bolts from the center bridge section (see illustration provided in the installation section of this manual).
6. Remove center dead bridge (if applicable) and **SET TO THE SIDE**. This dead section should be loaded on the truck last and **ON TOP** of the live weigh modules. If the center bridge is shorter than the live modules the self-contained frame will be **WILL BE DAMAGED**.
7. Remove spacer channels (if applicable) and place them on top of the center dead bridge.
8. Remove the approaches, steel or stone. Unbolt the bulkheads and place them on top of the center dead section.
9. Hook your chains to the main structural beams found under the manhole covers and load the modules on the trailer for shipment. **DO NOT** hook onto the smaller 3” I-beam stringers, the deck plate or side channel iron skirts. Replace the manhole covers **BEFORE** stacking the next module.
10. Load the center dead section **ON TOP** of the live weigh modules. The spacer bars and bulkheads should be loaded on top of the center section.
11. Box up the indicator (and printer) and place in the cab of the truck. This equipment **MUST** be kept dry.



**SUMMATION BOX HOFFMAN ENCLOSURE HJ1008HW**



MAIN CABLE FROM SCALES TO SECTION ADJUST BELDON CABLE #8778 WIRE COLORS


BLK/GRN PAIR USE GRN +EXC SEC 1  
BLK/YEL PAIR USE YEL +EXC SEC 2

YEL/BLK PAIR USE BLK -EXC ALL SEC  
BLK/WHT PAIR USE WHT +SIG ALL SEC  
BLK/RED PAIR USE RED -SIG ALL SEC  
SHEILD ALL TOGETHER

SECTION ADJUST POTS


BELDON CABLE #8723

GRN +EXC  
BLK -EXC  
WHT +SIG  
RED -SIG  
SHEILD BARE



SECTION ADJUST BOX NEAR INDICATOR HOFFMAN ENCLOSURE #A-806CH


AS SHOWN SEC. 1 & 2



LOAD CELL WIRING  
80210 DBL BEAM  
+EXC = RED  
-EXC. = BLK  
+SIG = GRN  
-SIG = WHT

L/C NUMBERING AT SCALE

AS SHOWN SEC. 3 & 4



BLK/BLU PAIR USE BLU +EXC SEC 3  
GRN/BLK PAIR USE BLK +EXC SEC 4  
YEL/BLK PAIR USE BLK -EXC ALL SEC  
BLK/WHT PAIR USE WHT +SIG ALL SEC  
BLK/RED PAIR USE RED -SIG ALL SEC  
SHEILD ALL TOGETHER  
WIRE SEC 1 + EXC INTO LOAD CELL POS 5 + EXC. IN J-BOX OF OTHER SCALE  
WIRE ALL THE OTHER 4 WIRES INTO CELL POS. 7 IN THE SAME BOX

RUN BELDON 8778 CABLE FROM J-BOX TO J-BOX ALONG INSIDE OF LOWER FRAME

TO DIGITAL SEE OWNERS MANUAL

BELDON CABLE #8723

SECTION ADJUST BOX

BELDON CABLE #8778

NOTE THE BOARD WILL HAVE 5 SECTIONS AND MAY BE WIRED IN SECTION 1 AND 2 INSTEAD OF 4 & 5

**LOADMASTER**

SCALE AND ELECTRONICS  
HOLTGREVEN SCALE AND ELECTRONICS CORP.  
10000 WOODLAND AVENUE  
PINDRAY OHIO 45640  
(419) 422-4778

TITLE: WIRING DIAGRAM FOR 2 MODULE RENTAL  
DATE: 8-6-08 DRN BY: MARK HOLTGREVEN  
SCALE: N/A DWG NO: 241-1122-2

# FT2 PORTABLE VEHICLE SCALE

## GENERAL

The LOADMASTER FT2 Portable Vehicle Scale is simply the standard FT2 with a self contained frame. Installation is a matter of placing on a smooth level surface, piling up stone for approaches and plugging in. That is it! (Note: Concrete footers recommended for any installation over 3 Months)

## CONFIGURATION

Standard module lengths are available as well as custom sizes. Each module is completely self supporting with 4 load cells. Modules can be placed end to end (or side by

side) and summed electrically for an unlimited combination of sizes and capacities.

## FEATURES

- Only 15½" tall (less than half of most portable vehicle scales)
- Same free floating deck as every other FT2 Motor Truck Scale
- Top access to all Load Cells and Junction Boxes
- Fully concealed and conduited wiring within the structure
- All Junction Boxes are fiberglass with NEMA 4X rating



PART NUMBER	#OF SECTIONS	CAPACITY (Tons)		PLATFORM LENGTH	SHIPPING	
		GROSS	CLC		10' WIDE	11' WIDE
156-3251-x	(2)	40	40	10'	6,300#	6,800#
-3255-x				12'	6,800	7,045
-3252-x				15'	7,900	8,200
-3253-x				17.5'	8,700	8,950
-3254-x				20'	10,050	10,375
156-xxxx-0	Primed and Finish Painted Steel (Standard)					
-xxxx-2	Hot Dip Galvanized (Optional)					
-xxxx-3	2-Part Epoxy Paint Finish (Optional)					
-xxxx-4	11' Wide					

Part Number Example:

156-3252-2 is a 15' x 20', 40 Ton "FT2" Portable Vehicle Scale with Hot Dip Galvanized Finish.

- NOTES:**
1. Custom sizes are available and in most cases carry no additional engineering charges.
  2. Accuracy will be as set forth in NBS Handbook 44. Class III L.
  3. All Loadmaster FT2 products are warranted against manufacturing defects for a period of two (2) years.
  4. Lightning protection kit included.



420 E. Lincoln Street • Findlay, Ohio 45840 • 419/422-4779  
Division of: Holtgreven Scale & Electronics Corp.



*"a preferred name in load cell technology"*

## Model 80210

### Double Ended Shear Beam Load Cell

#### FEATURES:

- 20k to 200k pounds capacities
- Low profile design
- Nickel/Chrome plated high alloy tool steel
- Complete environmental protection
- NTEP Certified versions available for Class III L 10,000 divisions
- Factory Mutual (F.M.) Approved †



**NTEP C.O.C. #90-083A2**

#### DESCRIPTION:

The Model 80210, a double ended shear beam load cell, is ideally suited for tough environments associated with truck scales. Its construction of high alloy tool steel provides optimum protection under impact loading and adverse conditions. The cell is environmentally protected with two waterproof seals and nickel/chrome plating to assure resistance against corrosion.

#### PERFORMANCE SPECIFICATIONS

<b>Standard Capacities (lbs.):</b>	20K, 30K, 40K, 50K, 60K, 65K, 75K, 100K, 150K, 200K
<b>Excitation Voltage:</b>	10VDC - Maximum 15VDC
<b>Rated Output:</b>	3.0 mV/V ± .1%
<b>Non-Linearity:</b>	< 0.03% FSO (Full Scale Output)
<b>Hysteresis:</b>	< 0.02% FSO
<b>Non-Repeatability:</b>	< 0.01% FSO
<b>Zero Balance:</b>	±1.0% FSO
<b>Bridge Resistance:</b>	700 ± 7.0 ohms
<b>Safe Overload:</b>	150% of Rated Capacity
<b>Side Load Discrimination:</b>	500:1
<b>Temperature:</b>	
<b>Compensated Range:</b>	0 - 150 deg. F
<b>Effect on Output:</b>	< 0.0008% FSO/deg. F
<b>Effect on Zero:</b>	< 0.0011% FSO/deg. F
<b>Finish:</b>	Electroless Nickel/Chrome Plated




# Model 80210



CAPACITY LBS.	A	B	C	D	E	F	G	H	J
20K - 40K	8.25	7.25	2.44	1.94	2.00	1.63	0.50	.25	.50
50K - 150K	10.25	8.50	2.90	2.90	2.40	2.05	1.00	.25	1.00
200K	11.50	10.00	3.40	3.40	2.75	2.35	1.50	.40	1.50

## WIRING

- INPLT      OUTPUT      SHIELD
- RED (+)    GREEN (+)
- BLACK (-)    WHITE (-)
- COMPRESSION POSITIVE**



\* NOTE 20K - 40K 40 FT CABLE, 50K - 200K 60 FT CABLE

† Factory Mutual Systems approved as intrinsically safe when installed per F.M. approved installation drawing. Contact ARTECH sales department for details.

Represented by:



1966 Keats Drive, Riverside, CA 92501

